



SelfAd Tissue Stencil Instructions

1. Ensure that the glass that is being engraved has been washed or cleaned and is completely dry.
2. Carefully peel off the white release paper from the back of the SelfAd stencil. For larger items it is easier to peel back and cut off about 20mm of the release paper which will allow the stencil to be positioned on the glass before removing the remainder of the release paper.
3. Once the stencil is in the correct position on the glass, press down from the centre to the top and bottom of the stencil. Do the same with the right hand side and left hand side ensuring that there are no creases in the tissue.
4. Once the stencil is completely flat on the glass, roll with our 50mm SelfAd (stock code PB20) roller to ensure it is fully stuck to the glass.
5. Blast the stencil with 280/320 white aluminium oxide (stock code PB24) at approximately 25 to 30psi, depending on the age of the abrasive.
6. To ensure all of the stencil has been sandblasted it is best to start blasting in the top left hand corner and blast the stencil from left to right whilst moving from the top to the bottom of the design.
7. Once all of the stencil has been blasted hold it up to the light to ensure no areas have been missed.
8. Place the glass in a bowl of warm soapy water where the stencil will float off the glass.
9. Dry and inspect the glass to ensure the design has been engraved correctly.

If you require any assistance please do not hesitate to contact us.

Edward House, 2 Westerby Road, Middlesbrough, Cleveland TS3 8TD

Telephone 01642 207313

sales@glassengravingsupplies.co.uk